


- F1,F2 - Fuse
- GV1,GV2 - Gasvalve
- H1,H2 - Alarm light
- IS - Ionization bar
- LD2 - Pressure switch
- RT - Room thermostat
- VLV - Combustion air fan

Internal wiring



External wiring

